

How to attach "OEM" style STi Thumbwheel Control:

If you have the original connector and harness to the control simply insert corresponding wire attached to the pins depicted below corresponding to correct color on 3 wire 22 AWG cable terminal. If not then solder the wires directly to the corresponding pins on the STi control.

- Red → Pin #3
- Black → Pin #2
- Green → Pin #1

